

4000 Series Release Notes

dBm Optics

August 22, 2007

For a brief overview of changes in each release, please see Appendix .

Firmware Release 4.57.016

A hard-reboot is required to gain access to the new kernel

New Features or Changes

- Support for Matrix Switch type added
- Measurement Diagnostic tool added to “Special Measurements”
- This release includes a new kernel in order to implement DMA hard-drive access

Bugs Fixed

- Santec laser loses communication
- Saving files to USB Flash causes GUI reboot
- Channel card communication/read errors (DMA fix)
- Wavelength Error trace does not return wavelengths
- Polarization State Generator view does not show state
- Random lockup when performing DarkCal from the GUI
- Equipment with no channel cards lock up after a few days
- Querying *OPC? too quickly after :INIT can return an incorrect value
- :Fetch:Data?, :Fetch:Header?, and :Fetch:Trace? slow down instrument
- Cycling through a non-measurement view breaks the “Measure” button

Known Issues

- No issues have been reported at this time, please visit <https://bugzilla.dbmoptics.com/> or contact your dBm Optics representative to report issues.

Firmware Release 4.56.015

New Features or Changes

- GUI now supports renaming files
- PDL RefSet wizard returns results much faster
- SplitCal now warns the user if the input power is too low

Bugs Fixed

- Unable to downgrade firmware
- Using the “Menu” key to close a menu causes a soft reboot
- Using GPIB to fetch back measurements causes GUI slowdown

Known Issues

- Santec laser loses communication
- Saving files to USB Flash causes GUI reboot
- Channel card communication/read errors (DMA fix)
- Wavelength Error trace does not return wavelengths
- Polarization State Generator view does not show state
- Random lockup when performing DarkCal from the GUI
- Equipment with no channel cards lock up after a few days
- Querying *OPC? too quickly after :INIT can return an incorrect value
- :Fetch:Data?, :Fetch:Header?, and :Fetch:Trace? slow down instrument
- Cycling through a non-measurement view breaks the “Measure” button

Firmware Release 4.55.014

New Features or Changes

- Allow scaling on currently selected trace
- X-Axis is now maintained between sweeps
- Added ability to set a TLS wavelength offset
- Alternate Display can now be changed over SCPI
- “Active Displays” settings are retained on reboot
- Added more gas cell wavelengths for wavelength referencing
- Changing the sweep mode now changes the current Alternate Display

Bugs Fixed

- Remote module communication problem
- GUI displays WaveRef units as picoseconds
- Large SplitCal operation causes GUI lockup
- PDL RefSet Ignore/Use button does not work

Known Issues

- Using GPIB to fetch back measurements causes GUI slowdown
- This firmware release cannot be downgraded, please upgrade to 4.56.015 before attempting to downgrade to an earlier release.

Firmware Release 4.54.013

New Features or Changes

- Added Santec laser to TLS wizard
- Internal TLS screen available for all models, if installed

Bugs Fixed

- Graph gridlines do not match the axis labels

Known Issues

- Remote module communication problem
- GUI displays WaveRef units as picoseconds
- Large SplitCal operation causes GUI lockup
- PDL RefSet Ignore/Use button does not work

Firmware Release 4.53.012

New Features or Changes

- PDL Reference Set feature added
- Added support for GPIB control of Model 4300

Bugs Fixed

- Progress indicator starts at 75%
- Display takes a long time to render
- Santec laser not found

Known Issues

- Graph gridlines do not match the axis labels

Firmware Release 4.52.011

New Features or Changes

- Added TLS activity icon to top bar
- Improved support for absolute units
- Improve rendering time for large sweeps
- Enable numeric keypad for entering IP address
- Enable TLS view for non-4200 models with an internal TLS

Bugs Fixed

- Varous minor GUI fixes
- Various fixes to support model 4300
- Fix “loop” number of sweeps restarts the GUI

Known Issues

- Display takes a long time to render
- Progress indicator starts at 75%
- Santec laser not found

Firmware Release 4.51.010

New Features or Changes

- Fix version comparison for Web upgrades
- Fix problem with loss of autoranging configuration
- GUI Option to change the TLS Trigger Edge added
- Add GUI support for selecting the filename of saved measurement data

Bugs Fixed

- X-Axis displays unreadable text beneath values
- Y-Axis displays incorrect values on Time display

Known Issues

- No issues have been reported at this time, please visit <https://bugzilla.dbmoptics.com/> or contact your dBm Optics representative to report issues.

Firmware Release 4.50.009

New Features or Changes

- Added support for DUT Switch (option 3302)
- Added support for Source Switch (option 974)
- Added support for Internal TLS on model 4650

Bugs Fixed

- Improper calculation of ORL gain
- Y-Axis displays values for the previous sweep
- Improper Passthru command hangs instrument
- Long-running execution can cause the GUI to reset

Known Issues

- X-Axis displays unreadable text beneath values
- Y-Axis displays incorrect values on Time display
- **Performing an upgrade changes installed options**

Firmware Release 4.49.008

New Features or Changes

- Added +/- symbol to numeric keypad
- Support for Model 210 Channel Card added
- “Configure Y Axis” buttons now allow for nine decimal places
- “Configure Y Axis” dialog now shows numbers in the simplest form

Bugs Fixed

- Rel/Zero does not un-zero
- Autoranging reports errors in logfile
- Email Log to Tech Support locks GUI
- “Data From” button causes the GUI to crash
- GUI crashes infrequently with no user interaction

Known Issues

- Improper calculation of ORL gain
- Y-Axis displays values for the previous sweep
- Improper Passthru command hangs instrument
- Long-running execution can cause the GUI to reset

Firmware Release 4.48.007

New Features or Changes

- Better support for Variable Optical Attenuator
- Support for autoranging in Power Meter Mode
- Open/Save file dialogs now only require one click
- Save System Settings dialog allows selection of existing files

Bugs Fixed

- WaveRef II displays incorrect traces
- WaveRef II reading spacing returns to default on sweep with TLS installed
- Garbage GUI Version displayed in some circumstances
- Changing between dBm/mW does not properly update the output power dialog on the TLS

Known Issues

- Rel/Zero does not un-zero
- Autoranging reports errors in logfile
- Email Log to Tech Support locks GUI
- “Data From” button causes the GUI to crash
- GUI crashes infrequently with no user interaction

Firmware Release 4.46.006

New Features or Changes

- Auto-detect DHCP/BOOTP IP on cable insertion

Bugs Fixed

- GPIB Address can be set to 0
- Math traces can not be enabled
- Saved traces can not be enabled
- Digital Filtering does not update GUI correctly

- Incorrect firmware version shown until reboot
- Searching for DHCP IP with no DHCP server on the network bogs down GUI

Known Issues

- WaveRef II displays incorrect traces
- Garbage GUI Version displayed in some circumstances
- WaveRef II reading spacing returns to default on sweep with TLS installed
- Changing between dBm/mW does not properly update the output power dialog on the TLS

Firmware Release 4.44.005

Known Issues

This release did not repair the issues it was meant to, please see release 4.46.006.

Firmware Release 4.42.004

New Features or Changes

- Added Support for Switching
- New graphical rendering back-end
- Added command-passthru for controlled devices
- Additional method for accessing the “Remote Assistance” tool
- Storing Wavelength Referencing Sweep Data is now supported in the GUI
- Activating Wavelength Referencing now turns on the Wavelength Reference Channel

Bugs Fixed

- Unusable buttons display on Model 4100
- Unable to save data files directly to USB drive
- GUI performance degrades when running for several days
- GUI performs a soft-reset when sweeping continuously for several hours
- Execution of nearly simultaneous commands locks up the internal TLS

Known Issues

- GPIB Address can be set to 0
- Math traces can not be enabled
- Saved traces can not be enabled
- WaveRef II displays incorrect traces
- Digital Filtering does not update GUI correctly
- Incorrect firmware version shown until reboot
- WaveRef II reading spacing returns to default on sweep with TLS installed
- Searching for DHCP IP with no DHCP server on the network bogs down GUI

Firmware Release 4.40.003

New Features or Changes

- Added ORL Configuration Wizard

Bugs Fixed

- “Remote Assistance” button missing from GUI menu
- IP Address Dialog crashes when changing the IP

Known Issues

- Unusable buttons display on Model 4100
- Unable to save data files directly to USB drive
- GUI performance degrades when running for several days
- GUI performs a soft-reset when sweeping continuously for several hours
- Execution of nearly simultaneous commands locks up the internal TLS

Firmware Release 4.40.002

New Features or Changes

- Added support for changing the GPIB address
- Added support for Raw Wavelength Reference Traces
- Added a visual keypad for the Numeric Entry Dialog
- Added “Infinite Loop” sweep option to Model 4200

Bugs Fixed

- Changing the View or Update status of a trace remotely not reflected by the front panel
- Auto-ranging uses difficult max/min and division values
- PDL Graphs always autorange

Known Issues

- “Remote Assistance” button missing from GUI menu
- IP Address Dialog crashes when changing the IP

Firmware Release 4.34

New Features or Changes

- Support for markers when multiple graphs are displayed
- System Re-imaging using a USB DVD-ROM
- Improved data rendering performance
- Infinite “Sweep Repeat” Option

Bugs Fixed

- Repeated sweeps do not wait for GUI to update
- Legend overlapping with markers enabled
- Remote FTP access not responding

Known Issues

- Changing the View or Update status of a trace remotely not reflected by the front panel
- Auto-ranging uses difficult max/min and division values
- PDL Graphs always autorange

Firmware Release 4.32

New Features or Changes

- Remote assistance tool added (requires Internet access and service password)
- Soft reboot button added

Bugs Fixed

- Right arrow key causes soft reboot
- First touch-screen press does not work
- GUI settings do not always save on shutdown/reboot

Known Issues

- Repeated sweeps do not wait for GUI to update
- Legend overlapping with markers enabled
- Remote FTP access not responding

Firmware Release 4.28

New Features or Changes

- Support for Internal Polarization Controller
- Support for Current Controlled Lasers

Bugs Fixed

- Corrupted GPIB and Serial Device Driver configuration files

Known Issues

- The “right arrow” key can cause a soft reboot under a very specific set of circumstances
- First touch-screen press does not work, clicks the middle of the screen rather than the requested location
- GUI settings do not always save on shutdown/reboot

Firmware Release 4.26

New Features or Changes

- Trace Statistics now defaults to the first trace of the first channel rather than “All”
- Digital Smoothing now defaults to 11 readings rather than 101
- Align Polarization with DUT Dialogs Added
- Semi-Transparent Graph Foreground Labels
- Markers

Bugs Fixed

- Memory leaks greatly reduced performance over time
- Run-away task caused rotary knob to run slow
- Bottom status text too small

Known Issues

- There are corrupted GPIB and Serial Device Driver configuration files, if you are unable to update to Firmware Release 4.28 then please contact your dBm Optics representative for assistance.

Brief Firmware History

The table below shows which components of the 4000 Series Firmware were modified in each release. The GUI refers to the graphical rendering application that supplies the Front Panel on the instrument, the Core/Engine is the internal software that handles communications and processing of all commands, and Support Files are any operating system config files or applications.

Version	GUI	Core/Engine	Support Files
4.26	X	X	X
4.28	X	X	X
4.32	X	X	X
4.34	X	X	X
4.40.002	X	X	
4.40.003	X		
4.42.004	X	X	X
4.44.005	-	-	-
4.46.006	X	X	X
4.48.007	X	X	
4.49.008	X	X	
4.50.009	X	X	
4.51.010	X	X	
4.52.011	X	X	
4.53.012	X	X	
4.54.013	X	X	
4.55.014	X	X	X
4.56.015	X	X	X